

CHOPPER/BEATER/HERB SPINNER



1. Place the bowl on top of the base. To lock into place, slide the green tab from left to right.
2. Place the desired attachment (chopper/beater/spinner basket) onto the shaft located in the center of the bowl, then add food.
3. Place container lid on top of the bowl, insert push handle. Note: To operate push handle, slide grey button to the left.
4. To operate, place one hand on the lid and push down on handle until food is the desired consistency.



- Chops onions, carrots, potatoes, etc.
- Beats eggs, whip cream, etc.
- Dries any vegetables or herbs

For best results do not fill container more than 1/3 full.

GRATER



1. Place grater board on top of bowl, lock into place by pulling tab on side. To attach the blade: carefully insert blade into the open section of grater board. Ensure blade is secure prior to use.
2. To operate, place the food on the grater board. For safety, keep fingers away from the blades, and always attach the food to the food holder. Next, slide the food holder back and forth over the grater blades.
3. To open, pull on tab and lift

JUICER



1. Place juicer attachment on top of the bowl and base. To operate, place fruit half on juicer point. Then lightly push down and twist.

BLADE ATTACHMENTS



Caution!

- Sharp blades! Keep away from children!
- When using the grater attachment, always use the food holder
- When using the chopper, beater and herb spinner attachments, some foods may need to be cut into smaller pieces to fit easily into the container. Do not over fill.
- Top rack dishwasher safe
- Do not use abrasive detergents when cleaning
- Do not use bowl as a food storage container
- Not oven or microwave safe

TOTAL CHEF MULTI CHOPPER™

15PC FRESH PREP COMPONENTS

